BELMAR BUILDERS

Building Neighbourhoods

THE BIRKDALE

Belmar Builders Inc. tel. (705) 524-0440 email. info@belmarbuilders.com /belmarbuildersinc www.belmarbuilders.com

BELMAR BUILDERS
Building Neighbourhoods

The Birkdale



MAIN FLOOR

BELMAR BUILDERS
Building Neighbourhoods

THE BIRKDALE



SECOND FLOOR

BELMAR BUILDERS
Building Neighbourhoods

The Birkdale



LOWER LEVEL